

Front spoiler

DTM vehicle version only

1 - Self-tapping screw (19x)

- 2 Nm

2 - Front spoiler

- To remove, unscrew bolts -1-.
- On installation, start by attaching spoiler in centre of vehicle - arrow A-.
- Slide spoiler on left and right to rear as far as stop -arrows B- and tighten both rear bolts to 2 Nm.
- Also tighten remaining bolts (16x) to 2 Nm.

3 - Bumper cover

